

## CLUTCH

	Page
TROUBLE SHOOTING .....	8 - 1
ADJUSTMENT .....	8 - 2
CLUTCH & BRAKE PEDALS .....	8 - 3
Removal .....	8 - 3
Inspection .....	8 - 4
Installation .....	8 - 4
CLUTCH MASTER CYLINDER .....	8 - 4
Removal .....	8 - 5
Disassembly .....	8 - 5
Inspection .....	8 - 5
Assembly .....	8 - 5
Installation .....	8 - 6
CLUTCH RELEASE CYLINDER .....	8 - 6
Removal .....	8 - 6
Disassembly .....	8 - 6
Inspection .....	8 - 6
Assembly .....	8 - 7
Installation .....	8 - 7
CLUTCH .....	8 - 7
Removal .....	8 - 7
Disassembly .....	8 - 7
Inspection & Repair .....	8 - 9
Assembly .....	8 -10
Installation .....	8 -10



## TROUBLE SHOOTING

Symptoms & Probable CausesRemedies

## 1. Slippage

The clutch slipping will appear gradually with the followings.

- (a) No speed gains
- (b) Fuel consumption increases
- (c) Engine overheats
- (d) Not enough acceleration relative to engine rpm when the accelerating pedal is depressed suddenly.
- (e) Loses in power is evident when climbing a slope.

The clutch slippage can be detected immediately in case of "d", and "e", but as for the symptoms of "a", "b", and "c", they are sometimes taken for engine troubles.

Thus, diagnosis must be carefully made.

Try not to operate the car with a slipping clutch which may lead to excessive wear or burning of clutch facing.

- |  |                                  |
|--|----------------------------------|
| a. No play at clutch release fork end      | Adjust release cylinder push rod |
| b. No clutch pedal free-play               | Adjust master cylinder push rod  |
| c. Oil adhering to clutch facing           | Replace clutch disc              |
| d. Clutch facing worn out                  | Replace clutch disc              |
| e. Weak clutch diaphragm spring            | Replace diaphragm spring         |
| f. Deformed pressure plate and/or flywheel | Repair or replace                |

## 2. Improper disengagement

This symptom causes unpleasant noise (clutch or gear clash) when shifting the transmission gears into mesh, and makes the gear shift difficult. Especially this appears when shifting into reverse gear.

- |   |                                  |
|---|----------------------------------|
| a. Excessive clutch pedal free-play                             | Adjust master cylinder push rod  |
| b. Excessive free-play at release fork end                      | Adjust release cylinder push rod |
| c. Defective clutch retracting spring/s                         | Replace spring/s                 |
| d. Defective input shaft front bearing                          | Replace bearing                  |
| e. Worn splines of clutch disc hub                              | Replace clutch disc              |
| f. Excessive clutch disc run-out                                | Replace clutch disc              |
| g. Weak or deformed master cylinder and/or release cylinder cup | Replace cup                      |
| h. Fluid leakage from master cylinder and/or release cylinder   | Check and repair                 |
| i. Air in clutch hydraulic system                               | Bleed Air                        |

Symptoms & Probable Causes

Remedies

- |  |  |
|--|--|
| <p>3. Chattering<br/>Upon starting out the car with the clutch engaged half-way, entire body may vibrate.</p> <p>a. Clutch facing glazed</p> <p>b. Oil or grease on facing</p> <p>c. Weak or damaged clutch disc torsion rubbers</p> <p>d. Poor facing contact or excessive clutch disc run-out</p> <p>e. Warped pressure plate or fly-wheel</p> <p>f. Loose or worn engine mounting</p> <p>g. Loose rivets in clutch disc</p> | <p>Recondition the facing or replace clutch disc</p> <p>Replace clutch disc</p> <p>Replace clutch disc</p> <p>Replace clutch disc</p> <p>Correct or replace</p> <p>Tighten or replace</p> <p>Replace clutch disc</p> |
| <p>4. Noisy<br/>Find the origin of the noisy clutch by disengaging the clutch for "a", and "b" or engaging clutch for "c", "d", and "e".</p> <p>a. Worn or damage clutch release bearing</p> <p>b. Worn or damaged input shaft front bearing</p> <p>c. Loose clutch disc hub</p> <p>d. Cracked clutch disc plate</p> <p>e. Weak or damage clutch disc torsion rubbers</p>  | <p>Replace bearing</p> <p>Replace bearing</p> <p>Replace clutch disc</p> <p>Replace clutch disc</p> <p>Replace clutch disc</p>   |
| <p>5. Jerking<br/>Upon starting out the car with the clutch engaged half-way, the car jerks, and is not accelerated smoothly.</p> <p>a. Oil or grease on facing</p> <p>b. Worn facing or loose rivets</p> <p>c. Damaged or weak clutch disc torsion rubbers</p>  | <p>Recondition or replace clutch disc</p> <p>Replace clutch disc</p> <p>Replace clutch disc</p>  |

ADJUSTMENT

1. Clutch pedal.
- a. Adjust the clutch pedal height with the pedal stopper bolt to specified height which should be 195 mm (7.7") from the dash panel.
- b. Adjust the clutch pedal free-play with the master cylinder push rod. The specified free-play is 0.5 to 3.0 mm (0.02 ~ 0.12") at the top center of the pedal pad. Make this adjustment with the tension spring.




Fig.8-1 Clutch Pedal Height Y5049

c. Check the small hole in the master cylinder boot if it is at the underneath side.

## 2. Clutch release fork.

a. Jack the front end of the car, and support it on stands.




Fig.8-2 Clutch Release Fork  
Free-play X4228

b. In order to obtain the specified clearance between the clutch re-

lease bearing in operation, and the clutch diaphragm spring, the adjustment should be made with the release cylinder push rod.

The specified free-play at the clutch release fork end should be 2 to 3 mm (0.08 ~ 0.11").

## 3. Air bleeding.


Be sure that the reservoir does not run short of brake fluid during the air bleeding operation, and brake fluid does not drip on any painted surface.

a. Connect the vinyl pipe to the release cylinder bleeder plug, and put the other end of the pipe into a jar half filled with brake fluid.

b. Pump the clutch pedal to bleed the air from the system.

c. After air bleeding, check if the oil leakage is not present.

## CLUTCH & BRAKE PEDALS



1. Bolt
2. Collar
3. Cotter pin
4. Pin
5. Cushion
6. Pedal adjusting bolt
7. Lock nut
8. Washer
9. Bushing
10. Lock washer
11. Nut
12. Return spring
13. Clutch pedal
14. Brake pedal
15. Pedal pad

Fig.8-3 Clutch & Brake Pedals Components

Y5050

### Removal

1. Remove both pedal return spring (1) of the clutch pedal, and the

brake pedal.

Disconnect the stop lamp switch wires.

## 8-4 CLUTCH - Clutch & Brake Pedals, Clutch Master Cylinder

2. With the cotter pins removed, remove the pins (2) from the clutch and brake master cylinder push rods.
3. Remove the bolt (3) holding the pedals, then remove the clutch, and brake pedals (4) from the pedal bracket.  
Remove the collars, bushings, and the washers from the pedals.




Fig. 8-4 Clutch & Brake Pedals Removal V1265

### CLUTCH MASTER CYLINDER

#### Inspection

Inspect the followings, and repair or replace the part/s if necessary.

1. Check the bushings for wear, scores, and damage.
2. Check the collars and pins for wear and rough surface.
3. Check the pedals for twist, and bend.
4. Check the pedal bushing eyes, and pedal pads for wear.

#### Installation

Follow the removal procedures in the reverse order.

When bushings and collars are assembled, apply a coat of multipurpose grease on these items.

Adjust the pedal, refer to clutch pedal adjustment.




Fig. 8-5 Clutch Master Cylinder Components

Removal

1. Plug the master cylinder reservoir inlet.
2. Disconnect the clutch tube from the master cylinder.
3. Remove the clutch pedal return spring.  
Next, with the cotter pin removed, remove the pin to disconnect the push rod, and the pedal.
4. Remove the bolts mounting the master cylinder onto the dash panel, and remove the master cylinder.  
Do not spill any brake fluid on the paint surfaces.

Disassembly

1. Remove the reservoir filler cap, and drain the fluid.  
Remove the reservoir cap, and the float.
2. Unscrew the bolt attaching the reservoir onto the master cylinder body, and remove the reservoir.
3. Remove the push rod, and the boot from the master cylinder body.
4. Clamp the master cylinder body in a vise, and with a pipe wrench remove the master cylinder cap from the master cylinder body.
5. Remove the cylinder cup, cup spacer, spring, and the piston towards the front end of the master cylinder body.
6. Remove the hole snap ring, and the washer.

Inspection

Wash all disassembled parts thoroughly in brake fluid, and inspect for wear and scores.

1. Inspect the master cylinder bore for wear or scores.
2. Inspect the piston exterior for abnormal wear or scores.
3. Inspect the cylinder to piston clearance.  
If the clearance exceeds the limit, replace the piston and/or the cylinder.

Cylinder inner diameter:  
15.87 ~ 15.913 mm  
(0.625 ~ 0.626")

Piston diameter:  
15.811-15.838mm(0.622-0.623")

Specified clearance:  
0.032 ~ 0.102 mm  
( 0.001 ~ 0.004")

Clearance limit:  
0.15 mm (0.006")

4. Inspect the cylinder cups, and the cup spacer for scores, distortion or wear.
5. Inspect the piston return spring for proper spring tension. If too weak, replace the spring.

Free length:  
85.0 mm (3.346")

Installed length:  
63.4 mm (2.496")

Installed load:  
1.5 kg (3.3 lb)

6. Inspect the reservoir for scores, and deformation at the base.

Assembly

Follow the disassembly procedures in reverse order.

1. Before assembly, soak the components in brake fluid.



## 8-6 CLUTCH - Clutch Master Cylinder, Clutch Release Cylinder

2. It is recommended that the cylinder cups, cup spacer, and the gasket should be replaced at the time of assembly.
3. Secure the reservoir with the bolt and washer to the cylinder body. Tighten the bolt to 1.7 m-kg or 12 ft-lb torque.
4. Install the master cylinder cap with the gasket, and tighten the cap to 18.5 m-kg (134 ft-lb) torque.

### CLUTCH RELEASE CYLINDER

1. Nut
2. Lock washer
3. Stud bolt
4. Clutch release cylinder
5. Cylinder cup
6. Retracting spring
7. Plug cap
8. Bleeder plug
9. Cylinder cup
10. Release cylinder piston
11. Boot
12. Push rod No.1
13. Lock nut
14. Push rod No.2




Fig.8-6 Clutch Release Cylinder Components

G0066

### Removal

1. Plug the master cylinder reservoir filler cap.
2. Disconnect the flexible hose from the release cylinder.
3. Disconnect the release fork retracting spring from the release cylinder.
4. Loosen the lock nut, and screw in the push rod No.2 into the push rod No.1. Remove the nuts securing the release cylinder to the clutch housing, then remove the clutch release cylinder.

### Disassembly

1. Remove the push rod No.1 together with the push rod No.2, and the boot.
2. Pull out the piston together with the cylinder cups.
3. Remove the bleeder plug.

### Inspection

Wash all disassembled parts thoroughly in brake fluid, and inspect for wear and scores.

Replace any defective part/s.

1. Inspect the release cylinder bore

### Installation

Follow the removal procedures in the reverse order.

1. Bleed the air from the hydraulic system.
2. Adjust the clutch pedal free-play.



for abnormal wear, and scores.

2. Inspect the piston surface for abnormal wear, and scores.
3. Inspect the cylinder to piston clearance.  
If the clearance exceeds the limit, replace the piston and/or the cylinder.

Cylinder bore diameter:  
19.050 ~ 19.102 mm  
(0.750 ~ 0.752")

Piston diameter:  
18.995 ~ 19.020 mm  
(0.748 ~ 0.749")

Specified clearance:  
0.030 ~ 0.107 mm  
(0.001 ~ 0.004")

Clearance limit:  
0.15 mm (0.006")




Fig.8-7 Cross Sectional X4073  
View of Release Cylinder

4. Inspect the cylinder cups for wear, scores, and deformation.

### Assembly

Follow the disassembly procedures in the reverse order.

1. Before assembly, soak the components in brake fluid.
2. It is recommended that cylinder cups should be replaced at the time of assembly.

### Installation

Follow the removal procedures in the reverse order.

1. Bleed the air from the hydraulic line.
2. Adjust the clutch release fork free play to 2 ~ 3 mm (0.08 ~ 0.11").


### CLUTCH

### Removal

1. Remove the engine together with the transmission from the car. Refer to ENGINE Removal.
2. Remove the transmission and clutch housing from the cylinder block.
3. Punch the mating marks on the clutch cover, and the flywheel to facilitate in relocating the original position upon assembly.
4. Remove the bolts securing the clutch cover to the flywheel, then remove the clutch cover assembly, and the clutch disc.
5. If the input shaft front bearing is to be replaced, remove it using the Input Shaft Front Bearing Pulver 09303-35010.  
To install the bearing, use the Input Shaft Front Bearing Replacer 09304-30012.

### Disassembly

1. Before disassembly, inspect the clutch pressure plate installed load with a tester.  
Many types of tester are available for use. Therefore, it is recommended that the gauge manufacturer's instructions be followed when performing the test.  
The specified load is 422 ~ 458 kg (928.4 ~ 1,007.6 lb) and the limit is 365 kg (803 lb).



- |                              |                             |
|------------------------------|-----------------------------|
| 1. Clutch disc               | 12. Clutch pressure plate   |
| 2. Diaphragm spring set bolt | 13. Clutch diaphragm spring |
| 3. Lock nut                  | 14. Clutch pivot ring       |
| 4. Release bearing           | 15. Clutch cover            |
| 5. Bearing clip              | 16. Lock washer             |
| 6. Release bearing hub       | 17. Bolt                    |
| 7. Clutch release fork       | 18. Retracting spring       |
| 8. Release fork ball         | 19. Boot                    |
| 9. Screw                     | 20. Boot plate              |
| 10. Lock washer              | 21. Lock washer             |
| 11. Retracting spring        | 22. Bolt                    |

Fig.8-8 Clutch Cover Assembly & Fork Components Y5051

2. Punch the mating marks on the clutch cover, and the pressure plate to facilitate in relocating the original position upon assembly.




Fig.8-9 Removing Retracting Spring W0371

3. Remove the retracting springs, and separate the clutch cover, and the pressure plate.
4. Loosen and remove the clutch diaphragm spring set bolt nuts, and remove the diaphragm spring, and the clutch pivot rings.
5. Unhook the release bearing hub clips, and remove the release bearing together with the bearing hub.
6. Remove the bolts mounting the release fork boot to the clutch housing, and remove the release fork.

### Inspection & Repair

Wash all parts, and inspect for wear, scores, and other defects. Repair or replace if necessary.

Never wash the clutch disc in cleaning solvent.

The release bearing is impregnated with lubricant, and should not be immersed in solvent.

#### 1. Clutch disc.

a. Inspect the facing for wear, glazed surfaces, oil soaked condition or warpage.

If the depth from the facing surface to the rivet head is less than 0.3 mm (0.012") or if the rivet holes are enlarged or the rivets are loose, replace the clutch disc assembly.

If the glazed surface is slight, the facing surface may be dressed with an emery cloth to remove the glaze.

If the facing is oil soaked slightly, the facing surface may be washed with gasoline.

b. Check the clutch disc facing run-out with a dial gauge. If the run-out exceeds 0.5 mm or 0.02", replace the clutch disc assembly.

c. Check the spline in the disc hub, and assure that the hub will slide freely on the input shaft spline. If worn, replace the clutch disc assembly.

d. Check the torsion rubbers for damage or deformation.

#### 2. Clutch cover & pressure plate.

a. Inspect the contacting portions with the clutch cover, and pressure plate for abnormal wear.

b. Inspect for perfect uniform contact with the clutch disc facing. If the contacting surface is scored or worn, the surface may be dressed with a fine emery cloth, or finished on a surface grinder if necessary.

c. Inspect the retracting springs for break, damage or weakness.

d. Check the pivot rings for abnormal wear on the contact surface with the diaphragm spring, and the diaphragm spring set bolts.

e. Check the diaphragm spring set bolts for abnormal wear at the pivot ring contacting point.

3. Diaphragm spring.
  - a. Inspect the diaphragm spring for abnormal wear on the release bearing contact surface, and the pivot ring contact surface.
  - b. Inspect the diaphragm spring for cracks.
4. Release bearing, hub & release fork.
  - a. Inspect the release bearing for abnormal wear, and roughness on the diaphragm spring contact surface or noise.
  - b. Check the release bearing hub for wear on the release fork contact surface.
  - c. Check the release fork for wear, and roughness on the bearing hub contact surface, and the release fork ball.

### Assembly

1. Place the clutch cover with inside out, and position the pivot ring in the clutch cover, aligning the recess in the pivot ring with one of the set bolt holes. Place the diaphragm spring over the pivot ring, then put the other pivot ring on the diaphragm spring, lining up the recess in the ring as done previously.




Fig. 8-10 Position of Pivot W0369  
Rings

2. Install the diaphragm spring set bolts, then tighten the nuts to 0.8 to 1.0 m-kg (6 ~ 7 ft-lb) torque. The nuts should be tightened symmetrically.
3. Assemble the pressure plate, and the clutch cover aligning the mating marks carefully, then install the diaphragm spring to the pressure plate so that there is no clearance between the retracting springs, and the diaphragm spring.
4. Assemble the release fork, boot, release bearing with hub, and the two hub clips.

### Installation

Follow the removal procedures in the reverse order.

1. When assembling the clutch cover assembly, and the clutch disc, use the Clutch Guide Tool 09301-36010.
2. Line up the mating marks carefully on the flywheel, and the clutch cover when assembling.
3. Tighten the bolts securing the clutch cover to the flywheel to 0.8 ~ 1.3 m-kg (6 ~ 9 ft-lb) torque.